



Thank You for your purchase from SynthGraphics!

JD-XA INSTALLATION TIPS:

1. Remove slider caps and pot knobs.
2. Do not try installing the overlay in one attempt/shot.
3. DO NOT remove sticky back protective sheet. Align the new overlay into place and tape it into position using blue painters tape or mixing board tape (as shown).
4. Now pull back the protective sheet and gently apply the overlay from the TOP down.
5. Now remove the tape.
6. If satisfied with alignment you can now firmly press the overlay down. The 3M adhesive will achieve full bond in 24-48hrs. It's OK to use the JD-XA in the meantime, the overlay will not slip or move.
7. Reinstall slide caps and pot knobs.

NOTE: for the bender panel, tape from the side and go left to right rather than top to bottom. See last photo.

Enjoy!

Jamie
www.SynthGraphics.com

Visit us on Facebook and post your photos
www.facebook.com/synthgraphics

